



# USER MANUAL

## Industrial Grade Managed Ethernet Switches

CLI Configuration User Manual

Content

Chapter 1      System Status Command .....	10
1.1System Information .....	10
1.1.1show version .....	10
1.1.2show clock.....	10
1.2System Log .....	10
1.2.1show logging .....	10
1.3Port Statistics .....	11
1.3.1show interface .....	11
1.4 LACP Status .....	11
1.4.1show lacp neighbor .....	11
1.5 STP Status .....	12
1.5.1 show spanning-tree .....	12
1.5.2 show spanning-tree interface.....	12
1.6LLDP Status .....	13
1.6.1show lldp neighbors .....	13
1.7 Layer 2 Forwarding List .....	13
1.7.1 show mac address-table .....	13
1.8 Loop-Protect Status .....	15
1.8.1show loop-protect .....	15
Chapter 2    System Settings .....	16
2.1 IP Configuration .....	16
2.1.1 Ip address .....	16
2.1.2ip address dhcp .....	16
2.1.3 show ip interface .....	17
2.2 System log Configuration .....	17

2.2.1logging on .....	18
2.2.3 logging level .....	18
2.3 User Configuration .....	19
2.3.1 username name .....	19
2.3.2 show users .....	20
2.4 NTP Configuration .....	21
2.4.1 ntp .....	21
2.4.2 ntp server .....	22
2.4.3 show ntp status .....	22
3.1 Port Configuration .....	22
3.1.1duplex .....	22
3.1.3 flowcontrol .....	24
3.1.4shutdown .....	24
3.1.5 POE .....	24
poe mode plus,enable 30w .....	25
poe mode standard,enable 15.4w .....	25
no poe mode,disable the power .....	25
Switch(config-if)# poe mode standard .....	25
Switch(config-if)# no poe mode .....	25
Switch#show poe .....	25
3.2 Isolation .....	25
3.2.1Port pylan isolation .....	25
3.3 Port Monitor .....	25
3.3.1 Monitor destination .....	25
3.3.2 Monitor source.....	26
3.4 Port Security .....	26
3.4.1 access-list ace .....	26
3.5 Port Policy .....	27
3.5.1 access-list rate-limiter .....	27

Chapter 4 Advanced Configuration Command .....	27
4.1 Link Aggregation .....	27
4.1.1 aggregation mode .....	28
4.1.2 aggregation group .....	28
4.1.3 lacp .....	29
4.1.4 lacp key .....	29
4.1.5 lacp port-priority .....	29
4.1.6 lacp role .....	30
4.1.7 lacp timeout .....	30
4.2 VLAN Management .....	31
4.2.1 Vlan .....	31
4.2.2 Name .....	31
4.2.3 switchport mode .....	32
4.2.4 switchport access vlan .....	32
4.2.5 Switchport forbidden vlan .....	33
4.2.6 Switchport hybrid acceptable-frame-type .....	33
4.2.7 Switchport hybrid ingress-filtering .....	34
4.2.8 Switchport hybrid egress-tag .....	34
4.2.9 Switchport hybrid native .....	34
4.2.10 show vlan .....	35
4.3 VCL Configuration .....	35
4.3.1 switchport vlan mac .....	35
4.3.2 switchport vlan ip-subnet .....	36
4.3.3 switchport vlan protocol .....	36
4.3.4 vlan protocol .....	37
4.4 DHCP Snooping Configuration .....	37
4.4.1 ip dhcp snooping .....	37
4.4.2 ip dhcp snooping trust .....	37

4.4.3	show ip dhcp snooping interface .....	38
4.5	DHCP Server Configuration .....	39
4.5.1	ip dhcp server .....	39
4.5.2	ip dhcp pool .....	39
4.5.3	ip dhcp excluded-address .....	40
4.5.4	host/network .....	40
4.5.5	Lease time .....	41
4.5.6	dns .....	41
4.5.7	Default-router .....	41
4.5.8	Show ip dhcp .....	42
4.6	DHCP relay Configuration .....	42
4.6.1	ip dhcp relay .....	42
4.6.2	ip helper-address .....	43
4.6.3	ip dhcp relay information option .....	43
4.6.4	ip dhcp relay information policy .....	44
4.6.5	Show ip dhcp relay .....	44
4.7	IGMP Snooping Configuration .....	44
4.7.1	ip igmp-snooping .....	44
4.7.2	ip igmp-snooping vlan .....	45
4.7.3	ip igmp-snooping immediate-leave .....	45
4.7.4	ip igmp-snooping max-groups .....	46
4.7.5	ip igmp-snooping mrouter .....	46
4.7.6	ip igmp-snooping querier election .....	47
4.7.7	ip igmp-snooping querier address .....	47
4.7.8	ip igmp-snooping compatibility .....	47
4.7.9	ip igmp-snooping priority .....	48

4.7.10	ip igmp snooping robustness-variable .....	48
4.7.11	ip igmp-snooping query-interval .....	49
4.7.12	ip igmp-snooping query-max-response-time .....	49
4.7.13	ip igmp-snooping last-member-query-interval .....	50
4.7.14	ip igmp-snooping unsolicited-report-interval .....	50
4.7.15	show ip igmp snooping .....	51
4.8	MVR configuration .....	51
4.8.1	Mvr .....	51
4.8.2	Mvr vlan .....	52
4.8.3	Mvr name .....	52
4.8.4	mvr immediate-leave .....	52
4.8.5	ipmc range .....	52
4.8.6	ipmc profile .....	52
4.8.7	show mvr .....	52
4.8.8	show ipmc profile .....	53
4.9	Router Configuration .....	53
4.9.1	ip routing .....	53
4.9.2	interface vlan .....	54
4.9.3	ip address .....	55
4.9.4	ip route .....	55
4.9.5	show ip interface brief .....	55
4.9.6	show ip route .....	56
	Chapter 5 Network Security Command .....	56
5.1	MACaddress table .....	56
5.1.1	mac address-table static .....	56
5.1.2	mac address-table aging-time .....	57
5.1.3	show mac address-table .....	57
5.2	Storm Broadcast control .....	58
5.3	IP VerifySource .....	59

5.3.1	ip verify source .....	59
5.3.2	ip verify source translate .....	59
5.3.3	ip verify source limit .....	60
5.3.4	ip source binding interface .....	60
5.3.5	show ip verify source .....	61
5.4	ARP Inspection Configuration .....	61
5.4.1	ip arp inspection .....	62
5.4.2	ip arp inspection trust .....	62
5.4.3	ip arp inspection checking-vlan .....	63
5.4.4	ip arp inspection logging .....	63
5.4.5	ip arp inspection entry interface .....	63
5.4.6	ip arp inspection translate .....	64
5.4.7	ip arp inspection vlan .....	65
5.4.8	show ip arp inspection .....	66
5.5	ACL Configuration .....	66
5.5.1	access-list ace .....	66
5.5.2	Show access-list .....	67
5.6	STP Configuration .....	67
5.6.1	spanning-tree .....	67
5.6.2	spanning-tree mode .....	68
5.6.3	spanning-tree aggregation .....	68
5.6.4	spanning-tree auto-edge .....	69
5.6.5	spanning-tree bpdu-guard .....	69
5.6.6	spanning-tree edge .....	69
5.6.7	spanning-tree link-type .....	70
5.6.8	spanning-tree mst .....	71
5.6.9	spanning-tree restricted-role .....	71
5.6.10	spanning-tree restricted-tcn .....	72

5.6.11	show spanning-tree .....	72
5.7	Loop-protect configuration .....	73
5.7.1	loop-protect .....	73
5.7.2	loop-protect tx-mode .....	73
5.8	ERPS configuration .....	74
5.8.1	mep .....	74
5.8.2	erps .....	74
Chapter 6	Network Management Command .....	76
6.1	SSH Configuration .....	76
6.1.1	ip ssh .....	76
6.2	HTTP Configuration .....	76
6.2.1	ip http-server-server .....	76
6.2.2	ip http-server-redirect .....	77
6.3	LLDP Configuration .....	77
6.3.1	lldp .....	78
6.3.2	lldp holdtime .....	78
6.3.3	lldp transmission-delay .....	78
6.3.4	lldp timer .....	78
6.3.6	show lldp neighbors .....	78
6.4	802.1X Configuration .....	79
6.4.1	dot1x system-auth-control .....	79
6.4.2	dot1x port-control auto .....	79
6.4.3	dot1x port-control mac-based .....	80
6.4.4	dot1x port-control single .....	80
6.4.5	dot1x port-control force-unauthorized .....	80
6.4.6	dot1x re-authentication .....	81
6.4.7	dot1x authentication timer re-authenticate .....	81
6.4.8	show dot1x statistics .....	82
6.5	SNMP Configuration .....	82

6.5.1	snmp .....	82
6.5.2	snmp version .....	82
Chapter 7 System Maintenance Command.....		83
7.1.1	reload cold .....	83
7.2	Restore to default .....	83
7.2.1	reload defaults .....	83
7.3	ping testing .....	84
7.3.1	ping ip .....	84

## Chapter 1 System Status Command

### 1.1 System Information

دستورات show باید در محیط Privilege Mode نوشته شود.

#### 1.1.1 show version

```
Switch#show version
MEMORY      : Total=88580 KBytes, Free=75552 KBytes, Max=75329 KBytes
FLASH       : 0x40000000-0x40fffff, 256 x 0x10000 blocks
MAC Address  : 20-77-59-01-c1-27
SN          :
Previous Restart : Cold

System Contact : Web: www.sepitam.com
System Name   : Switch
System Location :
Timezone Offset : 0
System Time    : 1970-01-01T01:47:59+00:00
System Uptime  : 01:47:59

Active Image
-----
Image       : (primary)
Version     : V2.1
Date        : 2021-06-28T17:57:11+08:00

Alternate Image
-----
```

#### 1.1.2 show clock

```
Switch#show clock
System Time  : 1970-01-01T01:55:37+00:00
```

### 1.2 System Log

#### 1.2.1 show logging

**Switch#show logging**

Switch logging host mode is disabled  
Switch logging host address is null  
Switch logging level is informational

Number of entries on Switch 1:

Error : 0  
Warning : 0  
Notice : 4  
Informational: 1  
All : 5

ID Level Time & Message

1	Informational	1970-01-01T00:00:01+00:00	SYS-BOOTING: Switch just made a cold boot.
2	Notice	1970-01-01T00:00:02+00:00	LINK-UPDOWN: Interface Vlan 1, changed state to down
3	Notice	1970-01-01T00:00:07+00:00	LINK-UPDOWN: Interface Vlan 1, changed state to up.

## 1.3 Port Statistics

### 1.3.1 show interface

**Switch# show interface GigabitEthernet 1/1-8 status**

Interface	Mode	Speed & Duplex	Flow Control	Max Frame	Excessive	Link
GigabitEthernet 1/1	enabled	Auto	disabled	9600	Discard	Down
GigabitEthernet 1/2	enabled	Auto	disabled	9600	Discard	Down
GigabitEthernet 1/3	enabled	Auto	disabled	9600	Discard	1Gfdx
GigabitEthernet 1/4	enabled	Auto	disabled	9600	Discard	Down
GigabitEthernet 1/5	enabled	Auto	disabled	9600	Discard	Down
GigabitEthernet 1/6	enabled	Auto	disabled	9600	Discard	Down
GigabitEthernet 1/7	enabled	Auto	disabled	9600	Discard	Down
GigabitEthernet 1/8	enabled	Auto	disabled	9600	Discard	100fdx

## 1.4 LACP Status

### 1.4.1 show lacp neighbor

Command Description

For LACP Status

Parameter

N/A

Default

N/A

Command Mode

Privilege Mode

Example

**Switch#show lacp neighbor**

## 1.5 STP Status

### 1.5.1 show spanning-tree

Switch#show spanning-tree active						
CIST Bridge STP Status						
Bridge ID	:	32768.20-77-59-01-C1-27				
Root ID	:	32768.20-77-59-01-C1-27				
Root Port	:	-				
Root PathCost	:	0				
Regional Root	:	32768.20-77-59-01-C1-27				
Int. PathCost	:	0				
Max Hops	:	20				
TC Flag	:	Steady				
TC Count	:	0				
TC Last	:	-				
Port	Port Role	State	Pri	PathCost	Edge	P2P Uptime

### 1.5.2 show spanning-tree interface

Command Description

For the Spanning Tree port status

Parameter

N/A

Default

N/A

Command Mode

Privilege Mode

Example

**Switch#show spanning-tree interface GigabitEthernet 1/10**

## 1.6 LLDP Status

### 1.6.1 show lldp neighbors

Switch#show lldp neighbors
----------------------------

```
Local Interface : GigabitEthernet 1/3
Chassis ID     : A0-8C-FD-C4-2C-E5
Port ID        : A0-8C-FD-C4-2C-E5
Port Description :
System Name    :
System Description :
System Capabilities :
PoE Type       :
PoE Source     :
PoE Power      :
PoE Priority   :

Local Interface : GigabitEthernet 1/8
Chassis ID     : 192.168.4.7
Port ID        : 80-5E-C0-B4-B5-63
Port Description : WAN PORT
System Name    : SIP-T19P_E2
System Description : 53.84.203.3
System Capabilities : Bridge(+),
Telephone(+)
PoE Type       : PD Device,
PoE Source     : PSE
PoE Power      : 3.8 [W]
```

## 1.7 Layer 2 Forwarding List

### 1.7.1 show mac address-table

Switch#show mac address-table
-------------------------------

```
Type VID MAC Address Ports
Dynamic 1 00:0a:f7:4b:a4:49 GigabitEthernet 1/8
Dynamic 1 00:0c:29:17:14:62 GigabitEthernet 1/8
Dynamic 1 00:0c:29:22:b5:96 GigabitEthernet 1/8
Dynamic 1 00:0c:29:5b:0b:26 GigabitEthernet 1/8
Dynamic 1 00:0c:29:94:5f:62 GigabitEthernet 1/8
Dynamic 1 00:0c:29:c2:3b:ce GigabitEthernet 1/8
Dynamic 1 00:0c:29:f7:7f:57 GigabitEthernet 1/8
Dynamic 1 00:1c:27:11:f6:68 GigabitEthernet 1/8
Dynamic 1 00:1c:27:12:f3:b2 GigabitEthernet 1/8
Dynamic 1 00:22:0d:98:cf:07 GigabitEthernet 1/8
Dynamic 1 00:24:e8:f5:51:ba GigabitEthernet 1/8
Dynamic 1 04:42:1a:00:92:22 GigabitEthernet 1/8
Dynamic 1 04:42:1a:0a:b3:95 GigabitEthernet 1/8
Dynamic 1 04:42:1a:29:04:33 GigabitEthernet 1/8
Dynamic 1 18:70:3b:68:40:2d GigabitEthernet 1/8
Static 1 20:77:59:01:c1:27 CPU
Static 1 33:33:00:00:00:01 GigabitEthernet 1/1-14 CPU
Static 1 33:33:00:00:00:02 GigabitEthernet 1/1-14 CPU
Static 1 33:33:ff:01:c1:27 GigabitEthernet 1/1-14 CPU
Dynamic 1 3c:d9:2b:5d:3d:a8 GigabitEthernet 1/8
Dynamic 1 44:03:77:20:5d:44 GigabitEthernet 1/8
```

### 1.7.2 show mac address-table static

Switch#show mac address-table static			
Type	VID	MAC Address	Ports
Static	1	20:77:59:01:c1:27	CPU
Static	1	33:33:00:00:00:01	GigabitEthernet 1/1-14 CPU
Static	1	33:33:00:00:00:02	GigabitEthernet 1/1-14 CPU
Static	1	33:33:ff:01:c1:27	GigabitEthernet 1/1-14 CPU

### 1.7.3 show mac address-table count

Switch#show mac address-table count			
Port	Dynamic addresses		
GigabitEthernet 1/1	0		
GigabitEthernet 1/2	0		
GigabitEthernet 1/3	1		
GigabitEthernet 1/4	0		
GigabitEthernet 1/5	0		
GigabitEthernet 1/6	0		
GigabitEthernet 1/7	0		
GigabitEthernet 1/8	38		
GigabitEthernet 1/9	0		
GigabitEthernet 1/10	0		
GigabitEthernet 1/11	0		
GigabitEthernet 1/12	0		
GigabitEthernet 1/13	0		
GigabitEthernet 1/14	0		

Total learned dynamic addresses for the switch: 39

Total static addresses in table: 4

### 1.7.4 show mac address-table learning

Switch#show mac address-table learning			
Port	Learning		
GigabitEthernet 1/1	Auto		
GigabitEthernet 1/2	Auto		
GigabitEthernet 1/3	Auto		
GigabitEthernet 1/4	Auto		
GigabitEthernet 1/5	Auto		
GigabitEthernet 1/6	Auto		
GigabitEthernet 1/7	Auto		
GigabitEthernet 1/8	Auto		
GigabitEthernet 1/9	Auto		
GigabitEthernet 1/10	Auto		
GigabitEthernet 1/11	Auto		
GigabitEthernet 1/12	Auto		
GigabitEthernet 1/13	Auto		
GigabitEthernet 1/14	Auto		

### 1.7.5 show mac address-table interface GigabitEthernet 1/10

Switch#show mac address-table interface GigabitEthernet 1/10			
Type	VID	MAC Address	Ports
Static	1	33:33:00:00:00:01	GigabitEthernet 1/1-14 CPU
Static	1	33:33:00:00:00:02	GigabitEthernet 1/1-14 CPU
Static	1	33:33:ff:01:c1:27	GigabitEthernet 1/1-14 CPU

### 1.7.6 show mac address-table vlan 1

Switch#show mac address-table vlan 1			
Type	VID	MAC Address	Ports
Dynamic	1	00:0a:f7:4b:a4:49	GigabitEthernet 1/8
Dynamic	1	00:0c:29:17:14:62	GigabitEthernet 1/8
Dynamic	1	00:0c:29:22:b5:96	GigabitEthernet 1/8
Dynamic	1	00:0c:29:94:5f:62	GigabitEthernet 1/8
Dynamic	1	00:0c:29:c2:3b:ce	GigabitEthernet 1/8
Dynamic	1	00:1c:27:11:f6:68	GigabitEthernet 1/8
Dynamic	1	00:1c:27:12:f3:b2	GigabitEthernet 1/8
Dynamic	1	00:22:0d:98:cf:07	GigabitEthernet 1/8
Dynamic	1	00:24:e8:f5:51:ba	GigabitEthernet 1/8
Dynamic	1	04:42:1a:00:92:22	GigabitEthernet 1/8
Dynamic	1	04:42:1a:0a:b3:95	GigabitEthernet 1/8
Dynamic	1	04:42:1a:29:04:33	GigabitEthernet 1/8
Dynamic	1	14:1f:78:e4:8b:f3	GigabitEthernet 1/8
Static	1	20:77:59:01:c1:27	CPU
Static	1	33:33:00:00:00:01	GigabitEthernet 1/1-14 CPU
Static	1	33:33:00:00:00:02	GigabitEthernet 1/1-14 CPU
Static	1	33:33:ff:01:c1:27	GigabitEthernet 1/1-14 CPU
Dynamic	1	3c:d9:2b:5d:3d:a8	GigabitEthernet 1/8
Dynamic	1	44:03:77:20:5d:44	GigabitEthernet 1/8
Dynamic	1	44:03:77:20:5d:7e	GigabitEthernet 1/8
Dynamic	1	44:03:77:20:5d:88	GigabitEthernet 1/8

### 1.8 Loop-Protect Status

#### 1.8.1 show loop-protect

Switch#show loop-protect	
interface GigabitEthernet 1/1-10	
Loop Protection Configuration	
=====	
Loop Protection	: Disable
Transmission Time	: 5 sec
Shutdown Time	: 180 sec
GigabitEthernet 1/1	
-----	
Loop protect mode is enabled.	
Action is shutdown.	
Transmit mode is enabled.	
No loop.	
The number of loops is 0.	
Status is down.	
GigabitEthernet 1/2	
-----	
Loop protect mode is enabled.	
Action is shutdown.	
Transmit mode is enabled.	
No loop.	

## Chapter 2 System Settings

### 2.1 IP Configuration

```
Switch# show ip interface brief
```

Interface	Address	Method	Status
-----			
VLAN 1	192.168.2.1/24	Manual	UP

#### 2.1.1 Ip address

برای اعمال برخی از کانفیگ ها بر روی سوئیچ باید در محیط Mode Global، دستورات را وارد کنیم.

Command Description

Ip address, Switch Port Configuration for managing IP no ip address A.B.C.D, indicates deleting Port ip A.B.C.D

Parameter

N/A

Default

Enable

Command Mode

VlanPort Configuration Mode

Example

```
Switch(config)# interface vlan 1
```

```
Switch(config-if-vlan)# ip address 192.168.255.200 255.255.255.0
```

مراحل تغییر IP دستگاه

```
# configure terminal  
(config)# interface vlan 1  
(config-if-vlan)# ip address 192.168.2.106 255.255.255.0
```

#### 2.1.2 ip address dhcp

Command Description

ip address dhcp, Switch Configuration to manage ip (vlan1) automatic access (DHCP Sever will allot a dynamic IP for vlan 1 of the switch)

no ip address dhcp, indicating that disable management for IP DHCP allocation. (Static Manual Configuration Mode)

Parameter

N/A

Default

Enable

Command Mode

vlan Configuration Mode

Example

```
Switch(config) interface vlan 1
```

```
Switch(config-if-vlan)#ip address dhcp
```

### **2.1.3 show ip interface**

Command Description

For IP configuration of the port

Parameter

N/A

Default

Enable

Command ModePrivilege Mode

Example

```
Switch#show interface brief
```

**logging level warning / error / informational / notice**

## **2.2 System log Configuration**

Log Configuration Command :

- logging on
- logging host

### **2.2.1 logging on**

Command Description logging on,  
enable log server mode  
No logging on, disable logging Server mode

Parameter

N/A

Default

N/A

Command Mode Global

Mode

Example

**Switch(config)#logging on**

**Switch(config)#no logging on**

برای تنظیم host برای syslog از اسم یا IP استفاده شود تا در صورت تغییر سرور نیازی نباشد دستگاه را مجدد تنظیم کنیم.

### **2.2.2 logging host**

Command Description

Log Server IP Address Configuration

Parameter

Hostname //Log Server Realm Name or IP address

Default

N/A

Command Mode

Global Mode

Example

**Switch(config)#logging host 192.168.0.1**

### **2.2.3 logging level**

Command Description

Configuration of Log Level for the uploading server ;

Parameter

Error | warning | info

Default

N/A

Command Mode

Global Mode

Example

```
Switch(config)#logging level error
```

## 2.3 User Configuration

User Configuration Command :

```
username name
```

Note : name, indicating the account name, support max 18 characters ; password, support max 18 characters ;

<pre>Switch#show user-privilege</pre>
username admin privilege 15 password encrypted c3lzdGVt

### 2.3.1 username name

Command Description

```
username name privilege level password none|encrypted|unencrypted password
```

For add user / modify the password of an existed user / modify the administration authority of an existed user / modify the password and administration authority of an existed user

Level, the user account authority level, valid level( 1 is the lowest administration authority, 15 is the highest administration authority) ; no username name, deleting a existed account

Parameter

N/A

Default

N/A

Command Mode

Global mode

Example

```
Switch(config)# username test privilege 15 password encrypted test
```

//New account :test, Password :test, Authority :the highest administration authority ;

Password Type :ciphertext

```
Switch(config)#no username test
```

### 2.3.2 show users

#### Command Description

For all users configuration information of the switch

#### Command Mode

#### Privilege Mode

#### Example

```
Switch#show users
```

```
Line is vty 0.  
* You are at this line now.  
Connection is from 192.168.2.100:52526 by SSH.  
User name is admin.  
Privilege is 15.  
Elapsed time is 0 day 0 hour 27 min 21 sec.  
Idle time is 0 day 0 hour 0 min 0 sec.
```

هر کانفیگی که انجام داده باشید با دستور زیر مشخص می شود و یا به طور پیش فرض می توانید مشخصات سوئیچ را مشاهده کنید.

This command could also be used for checking all user account

```
Switch#show running-config
```

```
Building configuration...  
username admin privilege 15 password encrypted c3lzdGVt  
!  
vlan 1  
!  
!  
!  
!  
aggregation mode smac dmac ip port  
spanning-tree mst name 20-77-59-01-c1-27 revision 0  
poe management mode class-consumption  
poe supply 250  
snmp-server contact Web: www.sepitam.com  
!  
interface GigabitEthernet 1/1  
no spanning-tree  
!  
interface GigabitEthernet 1/2  
no spanning-tree  
!  
interface GigabitEthernet 1/3  
no spanning-tree  
!  
interface GigabitEthernet 1/4  
no spanning-tree  
!  
interface GigabitEthernet 1/5  
no spanning-tree  
!  
interface GigabitEthernet 1/6  
no spanning-tree  
!  
interface GigabitEthernet 1/7
```

```
no spanning-tree
!
interface GigabitEthernet 1/8
no spanning-tree
!
interface GigabitEthernet 1/9
no spanning-tree
!
interface GigabitEthernet 1/10
no spanning-tree
!
interface GigabitEthernet 1/11
no spanning-tree
!
interface GigabitEthernet 1/12
no spanning-tree
!
interface GigabitEthernet 1/13
no spanning-tree
!
interface GigabitEthernet 1/14
no spanning-tree
!
interface vlan 1
ip address 192.168.2.1 255.255.255.0
```

## 2.4 NTP Configuration

ntp Configuration Command : ntp server ..... show ntp status

### 2.4.1 ntp

Command Description

- ✓ ntp , Enable the NTP ;
- ✓ no ntp, Disable the NTP ;

Parameter

N/A

Default

N/A

Command Mode

Global Mode

Example

Switch(config)# ntp

Switch(config)# no ntp

### **2.4.2 ntp server**

Command Description

ntp server <index\_var> ip-address { <ipv4\_var> | <ipv6\_var> | <name\_var> } NTP

Server address or realm name configuration index\_var 1-5, Support 5 NTP servers

no ntp server index\_var , Delete a NTP address

Parameter

N/A

Default

N/A

Command Mode

Global Mode

Example

Switch(config)# ntp server 1 ip-address 200.194.203.55

Switch(config)# no ntp server 1 ipaddress

### **2.4.3 show ntp status**

Command Description

For NTP Server Configuration Information

Parameter

N/A

Default

N/A

Command ModePrivilege Mode

Example

Switch(config)#show ntp status

## **Chapter 3Port Configuration Command**

### **3.1 Port Configuration**

Port configuration command : duplex speed flowcontrol shutdown

#### **3.1.1 duplex**

Command Description

duplex { auto | full | half } no

duplex

Setting the duplex mode for the port. Noted: If there isn't any special requirement, please do not change the rate mode of the port. Or it will influence the port proper working.

Parameter

Parameter	ParameterCommand Mode
auto	Automatic
full	Full duplex
half	Half duplex

Default

All port is auto. The mode of optical port is fixed full duplex

Command Mode

Port configuration Mode

Example

```
Switch(config)# interface GigabitEthernet 1/1
```

```
Switch(config-if)# duplex full
```

```
Switch(config-if)# no duplex full
```

### 3.1.2 speed

Command Description

speed { 10 | 100 | 1000 | 10000 | auto }, Setting port rate no speed

Parameter

Parameter	ParameterCommand Mode
10   100   1000   10000	Port rate: 10M、100M、1000M、10000Mbps
Auto	Automatically setting port rate

Default

Electrical port is automatic as default, gigabit optical port is adaptive, 10 gigabit port is forced to 10000M ;

Command Mode

Port Configuration Mode

Note: Optical port rate is forced to 1000M and 10000M. Electrical port could be set to Auto, 10M, 100, and 1000M.

Example

```
Switch(config)# interface GigabitEthernet 1/1
```

```
Switch(config-if)# speed 1000
```

### 3.1.3 flowcontrol

Command Description

flowcontrol on/off, Enable and disable flow control function

Parameter

N/A

Default

Disable, gigabit optical port can not support flow control

Command Mode

Port Configuration Mode

Example

```
Switch(config-if)# flowcontrol on
```

```
Switch(config-if)# flowcontrol off
```

### 3.1.4 shutdown

Command Description

- ✓ shutdown, disable the port
- ✓ no shutdown, enable the port

Parameter

N/A

Default

Enable

Command Mode

Port Configuration Mode Example

```
Switch(config-if)# no shutdown
```

این دستور باعث می شود که یک اینترفیس فعال شود. فراموش نکنید که باید از دستور no shutdown در مد interface استفاده کنید.

### 3.1.5 POE

Command Description

- ✓ poe mode standard,enable 15.4w
- ✓ no poe mode,disable the power

show poe,display poe status poe mode plus,enable 30w Example

```
Switch(config-if)# poe mode plus  
Switch(config-if)# poe mode standard  
Switch(config-if)# no poe mode  
Switch#show poe
```

## 3.2 Port Isolation

### 3.2.1 pvlan isolation

Command Description

Port Isolation Configuration. Forbid the connection between ports under same vlan

Parameter

N/A

Default

N/A

Command Mode

Port Configuration Mode

Example

```
Switch(config)# interface GigabitEthernet 1/1-5  
Switch(config-if)# pvlan isolation //Isolate port 1~5  
Switch(config-if)# no pvlan isolation //cancel the isolation for the port 1~5
```

## 3.3 Port Monitor

### 3.3.1 Monitor destination

Command Description

- ✓ monitor destination, Enable the monitor destination port
- ✓ no monitor destination, Disable the monitor destination port

Parameter

N/A

Default

N/A

Command Mode

Global Mode

Example

```
Switch(config)# monitor destination interface GigabitEthernet 1/1
```

```
Switch(config)# no monitor destination
```

### **3.3.2 Monitor source**

Command Description

- ✓ monitor source, Enable the monitor source port
- ✓ no monitor source interface GigabitEthernet 1/2. Disable the monitor source port

Parameter

```
monitor source { { interface ( <port_type> [ <v_port_type_list> ] ) } | { { both | rx | tx }
```

port\_type : GigabitEthernet or XGigabitEthernet ;

Both/rx/tx : Mirror direction, indicating ingress and Egress/ ingress/ egress data of mirror monitor port.

Default

N/A

Command Mode

Global Mode

Example

```
Switch(config)# monitor source interface GigabitEthernet 1/2 both
```

```
Switch(config)# no monitor source interface GigabitEthernet 1/2
```

## **3.4 Port Security**

### **3.4.1 access-list ace**

Command Description access-list

ace,

Port Security Policy Entry Configuration

Parameter

N/A

Default

N/A

Command Mode

Global Mode

Example

```
Switch(config)# access-list ace 2 action deny frame-type ipv4 ip-protocol any logging shutdown
```

### **3.5 Port Policy**

#### **3.5.1 access-list rate-limiter**

Command Description access-list rate-limiter, ACL Band width Limit

Policy Configuration

Parameter

```
<RateLimiterList : 1~16> pps <PpsRate : 0-131071>
```

DefaultN/A

Command ModeGlobal Mode

Example

```
Switch(config)# access-list rate-limiter 4 pps 100000
```

//Limit for ACL Policy ID4 configuration: 1000000 pps

## **Chapter 4 Advanced Configuration Command**

### **4.1 Link Aggregation**

Static Aggregation Configuration Command :

- aggregation mode
- aggregation group Dynamic Aggregation

Configuration Command :

- lacp
- lacp key
- lacp port-priority
- lacp role
- lacp timeout

#### 4.1.1 aggregation mode

Command Description

aggregation mode {ip | smac | dmac | smac dmac | port }, aggregation load-balancing algorithm configuration no aggregation mode, aggregation load-balancing algorithm configuration to default Parameter

Parameter	ParameterCommand Mode
ip	load-balancing based on ip address
smac	load-balancing based on source mac address
dmac	load-balancing based on destination mac address
smac dmac	load-balancing based on source & destination mac address
port	load-balancing based on tcp / udp port number

Default load-balancing based on ip  
address

Command Mode

Global Mode

Example

Switch(config)# aggregation mode smac dmac

#### 4.1.2 aggregation group

Command Description

- ✓ aggregation group group-id, Configuration for port to an aggregation group
- ✓ no aggregation group, Configuration for deleting static aggregation for a group

Parameter

group-id, Aggregation group id

Default

N/A

Command ModePort Configuration Mode

Example

Switch(config)# interface GigabitEthernet 1/1-8

Switch(config-if)# aggregation group 2

Switch(config-if)# no aggregation group

#### **4.1.3 lacp**

Command Description

- ✓ lacp, Configuration for enable dynamic Aggregation of port
- ✓ no lacp, Configuration for disable dynamic Aggregation of port

Parameter

N/A

Default

N/A

Command Mode

Port Configuration Mode

Example

```
Switch(config)# interface GigabitEthernet 1/1-4
Switch(config)# lacp
Switch(config)# no lacp
```

#### **4.1.4 lacp key**

Command Description

Lacp key, Configuration for the key value of dynamic aggregation port

Parameter

<1-65535> key value, ranges for the setting value 1-65535 ; auto, key value at automatic settings ;

Default

auto

Command Mode

Port Configuration Mode

Example

```
Switch(config-if)# lacp key 100
```

#### **4.1.5 lacp port-priority**

Command Description

lacp port-priority <1-65535> , Configuration for the Lacp Port-priority

Parameter

<1-65535>, Ranges for priority, The value is less, the priority level is higher

Default

N/A

CommandMode

Port Configuration Mode

Example

```
Switch(config-if)# lacp port-priority 100
```

#### **4.1.6 lacp role**

Command Description

lacp role active | passive, Configuration for dynamic aggregation port role

Parameter

active | passive, Indicating the port role is active and passive respectively

Default

active

Command ModePort Configuration Mode

Example

```
Switch(config-if)#lacp role active
```

```
Switch(config-if)#lacp role passive
```

#### **4.1.7 lacp timeout**

Command Description

Lacp timeout fast | slow, Configuration for Lacp timeout selections

Parameter

fast | slow, indicating fast and slow respectively

Default

fast

Command ModePort Configuration Mode

Example

```
Switch(config-if)# lacp timeout fast
```

```
Switch(config-if)# lacp timeout slow
```

## 4.2 VLAN Management

Configuration Command :

- vlan
- name
- switchport mode
- switchport access vlan
- switchport forbidden vlan

Switchport hybrid acceptable-frame-type

Switchport hybrid ingress-filtering

Switchport hybrid native

Switchport hybrid egress-tag

show vlan

### 4.2.1 Vlan

Command Description

vlan { vlan\_list}, add vlan no vlan , delete vlan

Parameter

<vlan\_list> VLAN ID, valid ranges 1-4095,4095 should be kept, the real using ranges is 14094

Default

vlan 1, All port is vlan 1

Command Mode

Global Configuration Mode

Example

Switch(config)#vlan 2-3,6,9 //Add vlan 2,3,6,9 , 4 vlan ports

Switch(config)#no vlan 6,9 //Delete vlan 6,9

### 4.2.2 Name

Command Description

Name <vword32>, Setting vlan name

Parameter

<vword32> , vlan name

Default default

Command Mode

vlan configuration mode

Example

```
Switch(config)# vlan 2  
Switch(config-vlan)# name test123
```

#### 4.2.3 switchport mode

Command Description switchport mode {access | trunk | hybrid }

Parameter

Parameter	ParameterCommand Mode
access	Access mode
trunk	Trunk mode
Hybrid	Hybrid mode

Switch ports could support several modes as below:

Access Mode: The port is only under one vlan, and only send and receive the data marked with N/A.

Trunk Mode: The port could be connect with other switches, and could send and receive marked data.

Hybrid Mode: The port could be connect with PC, switches, and routers( It is the combination of Trunk mode and Access Mode)

Default Hybrid Mode

Command Mode

Port Configuration Mode

Example

```
Switch(config)# interface GigabitEthernet 1/2-4  
Switch(config-if)#switchport mode access  
Switch(config)# interface GigabitEthernet 1/1  
Switch(config-if)#switchport mode trunk
```

#### 4.2.4 switchport access vlan

Command Description

```
switchport access vlan { vlan-id}
```

Parameter

Parameter	ParameterCommand Mode
Vlan-id	Vlan ID ranges 1-4094

Default

Vlan 1

Command ModePort Configuration Mode

Example

```
Switch(config)#vlan 2
```

```
Switch(config)# interface GigabitEthernet 1/5-8
```

```
Switch(config-if)#switchport mode access
```

```
Switch(config-if)#switchport access vlan 2
```

#### **4.2.5 Switchport forbidden vlan**

Command Description

```
switchport forbidden vlan { add | remove} {vlan-id}
```

Parameter

Parameter	ParameterCommand Mode
add	enable vlan list
Remove	disable vlan list
Vlan-id	Vlan ID ranges1-4094

Default

Enable Vlan 1

Command ModePort Configuration Mode

Example

```
Switch(config)# interface GigabitEthernet 1/1
```

```
Switch(config-if)# switchport mode hybrid
```

```
Switch(config-if)# switchport forbidden vlan add 2
```

```
Switch(config-if)# switchport forbidden vlan remove 3-4
```

#### **4.2.6 Switchport hybrid acceptable-frame-type**

Command Description

```
Switchport hybrid acceptable-frame-type <all | tagged | untagged> Parameter
```

all | tagged | untagged enable/ disable hybrid port receiving data of all tag

Default

all

Command ModePort Configuration Mode

Example

```
Switch(config)# interface GigabitEthernet 1/1
```

```
Switch(config-if)# switchport hybrid acceptable-frame-type all
```

#### **4.2.7 Switchport hybrid ingress-filtering**

Command Description

- ✓ Switchport hybrid ingress-filtering, Enable Port hybrid ingress-filtering
- ✓ no switchport hybrid ingress-filtering , Disable Port hybrid ingress-filtering

Parameter

N/A

Default

Disable

Command Mode

Port Configuration Mode

Example

```
Switch(config)# switchport hybrid ingress-filtering
```

```
Switch(config-if)# no switchport hybrid ingress-filtering
```

#### **4.2.8 Switchport hybrid egress-tag**

Command Description

- ✓ Switchport hybrid egress-tag <all | none>
- ✓ port hybrid egress-tag configuration
- ✓ No switchport hybrid egress-tag

Parameter

<all | none>, indicating egress port tag and untag attribute

Default

Untag Port vlan

Command Mode

Port Configuration Mode

Example

```
Switch(config)# switchport hybrid egress-tag all
```

```
Switch(config-if)# no switchport hybrid egress-tag
```

#### **4.2.9 Switchport hybrid native**

Command Description

Switchport hybrid native vlan <vlan-id>, Configuration for hybrid port local vlan

Parameter

Vlan-id	Vlan ID ranges 1-4094
---------	-----------------------

Default

all

Command ModePort Configuration Mode Example

**Switch(config)# Switchport hybrid native vlan 2**

#### **4.2.10 show vlan**

Command Description

show vlan brief |id vlan-list| ip-subnet | mac |name | protocol | status

Parameter

For checking current vlan configuration according to vlan id & vlan name etc.

Default

N/A

Command Mode

Privilege Mode

Example

**Switch# show vlan brief**

**Switch# show vlan status**

**Switch# show vlan 2**

**Switch# show vlan ip-subnet**

### **4.3 VCL Configuration**

VCL Configuration Command :

- switchport vlan mac
- switchport vlan ip-subnet
- switchport vlan mapping
- switchport vlan protocol

#### **4.3.1 switchport vlan mac**

Command Description

- ✓ switchport vlan mac
- ✓ according to the vlan of MAC

- ✓ no switchport vlan mac

Parameter

N/A

Default

N/A

Command Mode

Port Configuration Mode

Example

```
Switch(config-if)# switchport vlan mac 00-00-00-00-00-01 vlan 2
```

```
Switch(config-if)# no switchport vlan mac 00-00-00-00-00-01 vlan 2
```

#### **4.3.2 switchport vlan ip-subnet**

Command Description

- ✓ switchport vlan ip-subnet, according to the vlan of sub network mask
- ✓ no switchport vlan ip-subnet, Delete the configuration according to the vlan of ip-subnet

Parameter

N/A

Default

N/A

Command Mode

Port Configuration Mode

Example

```
Switch(config-if)# switchport vlan ip-subnet id 1 10.0.0.1/255.255.255.0 vlan 1
```

```
Switch(config-if)# no switchport vlan ip-subnet id 1
```

#### **4.3.3 switchport vlan protocol**

Command Description switchport vlan protocol, Configurate the mapping of group name to vlan no switchport vlan mac

Parameter

```
switchport vlan protocol group <group_name> vlan <vlan_id>
```

Default

N/A

Command Mode

Port Configuration Mode

Example

```
Switch(config-if)# switchport vlan protocol group test vlan 2
```

```
Switch(config-if)# no switchport vlan protocol group test vlan 2
```

#### **4.3.4 vlan protocol**

Command Description

- ✓ vlan protocol eth2| llc | snap, Configurate the mapping of protocol to group
- ✓ no vlan protocol

Parameter

eth2 Ethernet-based VLAN commands llc LLC-based VLAN group snap SNAPbased VLAN group

Default

N/A

Command ModeGlobal Configuration Mode

Example

```
Switch(config)# vlan protocol snap 0xE02B 0x1 group test
```

```
Switch(config)# no vlan protocol snap 0xE02B 0x1 group test
```

### **4.4 DHCP Snooping Configuration**

DHCP Snooping Configuration Command :

- ip dhcp snooping
- ip dhcp snooping trust
- show ip dhcp snooping table

#### **4.4.1 ip dhcp snooping Command Description ip**

dhcp snooping, Enable DHCP Snooping no ip dhcp

snooping, Disable DHCP Snooping Parameter

N/A

Default

Disable

Command ModeGlobal Configuration Mode

Example

Switch(config)# ip dhcp snooping

Switch(config)# no ip dhcp snooping

#### **4.4.2 ip dhcp snooping trust Command Description ip**

dhcp snooping trust, Enable DHCP snooping trust no ip dhcp snooping trust, Disable DHCP snooping

Parameter

N/A

Default

Enable

Command ModePort Configuration Mode

Example

Switch(config-if)# ip dhcp snooping trust

Switch(config-if)# no ip dhcp snooping trust

#### **4.4.3 show ip dhcp snooping table**

Command Description

show ip dhcp snooping table, For checking DDHCP Snooping table

Parameter

N/A

Default

N/A

Command ModeGlobal Configuration Mode

Example

Switch(config)# ip dhcp snooping

Switch(config)# no ip dhcp snooping

#### **4.4.4 show ip dhcp snooping interface**

Command Description

show ip dhcp snooping interface, For checking DHCP Snooping trust mode

Parameter

N/A

Default

N/A

Command Mode

Privilege Mode

Example

```
Switch# show ip dhcp snooping interface GigabitEthernet 1/1
```

## 4.5 DHCP Server Configuration

DHCP Server Configuration Command :

```
ip dhcp server      ip  
dhcp pool  
host/network      lease  
time          default-router  
dns
```

```
Switch#show ip dhcp
```

### 4.5.1 ip dhcp server

Command Description

- ✓ ip dhcp server, Enable DHCP
- ✓ no ip dhcp server, Disable DHCP

Parameter

N/A

Default

Disable

Command Mode

Global Configuration Mode/vlan Port Configuration ModeExample

```
Switch(config)# ip dhcp server
```

```
Switch(config)# no ip dhcp server
```

```
Switch(config)# interface vlan 2
```

```
Switch(config-if-vlan)# ip dhcp server //Enable DHCP server allocating IP under vlan 2
```

```
Switch(config-if-vlan)# no ip dhcp server // disable DHCP server allocating IP under vlan 2
```

### 4.5.2 ip dhcp pool Command Description

ip dhcp pool <word>, Add dhcp address pool name      ip dhcp pool <word>, Deletespecified name  
DHCP address pool

Parameter

N/A

Default

N/A

Command Mode

Global Configuration Mode

Example

```
Switch(config)# ip dhcp pool vlan2_test1
```

```
Switch(config)# no ip dhcp pool vlan2_test1
```

#### **4.5.3 ip dhcp excluded-address**

Command Description

ip dhcp excluded-address, Setting DHCP excluded IP address

noip dhcp excluded-address, DeleteDHCP specified excluded IP address, excluding the DHCP Client, whose IP is not under the port.

Parameter N/A

Default

N/A

Command Mode

Global Configuration Mode

Example

```
Switch(config)# ip dhcp excluded-address 1.0.0.1 1.0.0.2
```

```
Switch(config)#no ip dhcp excluded-address 1.0.0.1 1.0.0.2
```

#### **4.5.4 host/network**

Command Description

Host <ip><subnet\_mask> , Configurate IP DHCP pool.

Network <ip><subnet\_mask> ,Configurate DHCP pool IP network segment( Max support 1K, could be extending to 4K)

No host|network <ip><subnet\_mask>, Delete DHCP Pool IP or network segment.

Parameter

<ip><subnet\_mask> , Indicating IP address and subnet mask respectively

Default

N/A

Command Mode

DHCP Pool Configuration Mode

Example

```
Switch(config)# ip dhcp pool test_pool
```

```
Switch(config-dhcp-pool)# host 3.0.0.1 255.0.0.0
```

```
Switch(config-dhcp-pool)# network 1.0.0.1 255.0.0.0
```

#### **4.5.5 Lease time**

Command Description      lease { <day> [ <hour> [ <min> ] ] | infinite } , Configurate address

DCHP pool IP lease

Parameter

{ <day> [ <hour> [ <min> ] ] | infinite } Default

infinite

Command Mode

DHCP Pool Configuration Mode

Example

```
Switch(config-dhcp-pool)# lease infinite
```

```
Switch(config-dhcp-pool)# lease 1 0 0
```

#### **4.5.6 dns**

Command Description

Dns <A.B.C.D>, Configurate DNS

Parameter

<A.B.C.D>, dns address

Default

N/A

Command Mode

DHCP Pool Configuration Mode

Example

```
Switch(config-dhcp-pool)# dns 8.8.8.8
```

#### **4.5.7 Default-router**

Command Description

Default-router <A.B.C.D>, Configurate DHCP Pool default gateway

Parameter

<A.B.C.D>, IP address of the gateway

Default

N/A

Command Mode

DHCP Pool Configuration Mode

Example

```
Switch(config-dhcp-pool)# default-router 1.0.0.100
```

#### 4.5.8 Show ip dhcp

Command Description

Show ip dhcp pool|server, For checking IP DHCP pool and server configuration

Parameter

N/A

Default

N/A

Command Mode

Privilege Mode

Example

```
Switch# Show ip dhcp pool
```

```
Switch# Show ip dhcp server
```

### 4.6 DHCP relay Configuration

DHCP relay Configuration Command :

- ip dhcp relay
- ip helper-address
- ip dhcp relay information option
- ip dhcp relay information policy
- show ip dhcp relay

#### 4.6.1 ip dhcp relay

Command Description

- ✓ ip dhcp relay, Enable the DHCP relay

- ✓ no ip dhcp relay, Disable the DHCP replay

Parameter

N/A

Default

Disable

CommandMode

Global Configuration Mode

Example

```
Switch(config)# ip dhcp relay
```

```
Switch(config)# no ip dhcp relay
```

#### **4.6.2 ip helper-address**

Command Description

ip helper-address ip\_addr, Configurate IP of relay server

Parameter

N/A

Default

N/A

Command Mode

Global Configuration Mode

Example

```
Switch(config)# ip helper-address 1.0.0.1
```

#### **4.6.3 ip dhcp relay information option** Command Description

- ✓ ip dhcp relay information option, Enable DHCP relay option mode
- ✓ no ip dhcp relay information option, disable DHCP relay option mode

Parameter

N/A

Default

Disable

Command Mode

Global Configuration Mode

Example

Switch(config)# ip dhcp relay information option

Switch(config)# no ip dhcp relay information option

#### **4.6.4 ip dhcp relay information policy**

Command Description

ip dhcp relay information policy {Replace|Keep|Drop},

Configurate DHCP relay information policy

Parameter

N/A

Default

N/A

Command ModeGlobal Configuration Mode

Example

Switch(config)# ip dhcp relay information policy drop

#### **4.6.5 Show ip dhcp relay**

Command Description

Show ip dhcp relay,For checking DHCP Relay Configuration

Parameter

N/A

Default

N/A

Command Mode

Privilege Mode

Example

Switch# show ip dhcp relay

### **4.7 IGMP Snooping Configuration**

igmp-snooping Configuration Command : ip igmp-snooping ip igmp-snooping vlan ip igmpsnooping immediate-leave ip igmp-snooping max-groups ip igmp-snooping mrouter ip igmpsnooping querier election ip igmp-snooping querier address ip igmp-snooping compatibility ip igmp-snooping priority ip igmp snooping robustness-variable ip igmp-snooping query-interval ip igmp-snooping query-max-response-time ip igmp-snooping last-member-query-interval ip igmp-snooping unsolicited-report-interval show ip igmp-snooping

#### **4.7.1 ip igmp-snooping**

Command Description

- ✓ ip igmp-snooping      Enable the igmp-snooping
- ✓ no ip igmp-snooping    Disable ip igmp-snooping

Parameter

N/A

Default

Disable

Command Mode

Global Configuration Mode, VLAN Configuration Mode or Configurate this command under Port Configuration Mode

Example

Enable igmp-snooping

Switch (config)# ip igmp snooping

#### **4.7.2 ip igmp-snooping vlan**

Command Description

- ✓ ip igmp-snooping vlan <vlan\_list> add IGMP Vlan
- ✓ no ip igmp-snooping vlan <vlan\_list> Delete IGMP Vlan

Parameter

Parameter	Parameter Command Mode
vlan_list	VLAN ID

Default

N/A

Command Mode

Configurate this command under Global Configuration Mode

Example add IGMP VLAN

Switch (config)# ip igmp snooping vlan 1

#### **4.7.3 ip igmp-snooping immediate-leave**

Command Description

- ✓ ip igmp-snooping immediate-leave      Enable the function .
- ✓ no ip igmp-snooping immediate-leave    Disable the function

Parameter

N/A

Default

Disable

Command Mode

Configurate the command under Port Configuration Mode

Examplefor Enable the function

Switch (config-if)# ip igmp snooping immediate-leave

#### **4.7.4 ip igmp-snooping max-groups**

Command Description

ip igmp-snooping max-groups <Throttling : 1-10>

For setting throttling numbers of port no ip igmp-snooping max-groups

For setting to default

Parameter

Parameter	ParameterCommand Mode
Throttling	Ranges 1-10

Default unlimited

Command Mode

Configurate the command under Port Configuration Mode Examplefor Setting Throttling of port at 10

Switch (config-if)# ip igmp snooping max-groups 10

#### **4.7.5 ip igmp-snooping mrouter**

Command Description

ip igmp-snooping mrouter , Enable the function

no ip igmp-snooping mrouter Disable the function

Parameter

N/A

Default

Disable

Command Mode

Configurate the command under Port Configuration Mode

Examplefor Enable the function

[Switch \(config-if\)# ip igmp snooping mrouter](#)

#### **4.7.6 ip igmp-snooping querier election**

Command Description

- ✓ ip igmp-snooping querier election Enable the function
- ✓ no ip igmp-snooping querier election Disable the function

Parameter

N/A

Default

Disable

Command Mode

Configurate the command under VLAN Configuration Mode

Examplefor enable the function

[Switch \(config-if-vlan\)# ip igmp snooping querier election](#)

#### **4.7.7 ip igmp-snooping querier address**

Command Description

- ✓ ip igmp-snooping querier address<ipv4\_icast> For setting ip igmp-snooping querier address
- ✓ no ip igmp-snooping querier address For setting to default

Parameter

Parameter	ParameterCommand Mode
ipv4_icast	querier address

Default

0.0.0.0

Command Mode

Configurate the command under Vlan configuration mode

Examplefor setting ip igmp-snooping querier addresss

[Switch \(config-if-vlan\)# ip igmp snooping querier address 192.168.2.1](#)

#### **4.7.8 ip igmp-snooping compatibility**

Command Description

- ✓ ip igmp-snooping compatibility auto/v1/v2/v3 For Setting IGMP compatibility in IGMP VLAN

- ✓ no ip igmp-snooping compatibility Setting IGMP compatibility in IGMP VLAN to default

Parameter

N/A

Default

IGMP-auto

Command Mode

Configurate the command under VLAN configuration Mode

Examplefor setting IGMP in VLAN into Forced IGMP V1

[Switch \(config-if-vlan\)# ip igmp snooping compatibility v1](#)

#### 4.7.9 ip igmp-snooping priority

Command Description

- ✓ ip igmp-snooping priority <CosPriority : 0-7> For setting the priority
- ✓ no ip igmp-snooping priority

For setting t he priority to default

Parameter

Parameter	ParameterCommand Mode
CosPriority	Priority Level Ranges 07

Default

0

Command Mode

Configurate the command under VLAN configuration mode

Examplefor setting priority level

[Switch \(config-if-vlan\)# ip igmp snooping priority 7](#)

#### 4.7.10 ip igmp snooping robustness-variable

Command Description

ip igmp-snooping robustness-variable <IpmcRv : 1-255> For setting RV

no ip igmp-snooping robustness-variable Setting RV to default

Parameter

Parameter	ParameterCommand Mode
IpmcRv	RV ranges 1-255

Default

2

Command Mode

Configurate the command under VLAN configuration mode

Examplefor setting RV

Switch (config-if-vlan)# ip igmp snooping robustness-variable 7

#### **4.7.11 ip igmp-snooping query-interval**

Command Description

ip igmp-snooping query-interval <IpmcQi : 1-31744>For setting QI

no ip igmp-snooping query-interval For setting QI to default

Parameter

Parameter	ParameterCommand Mode
IpmcQi	QI ranges 1-31744

Default

125

Command Mode

Configurate the command under VLAN configuration mode

Examplefor setting QI

Switch (config-if-vlan)# ip igmp snooping query-interval 70

#### **4.7.12 ip igmp-snooping query-max-response-time**

Command Description

- ✓ ip igmp-snooping query-max-response-time <IpmcQri : 0-31744> For setting QRI
- ✓ no ip igmp-snooping query-max-response-time For setting QRI to default

Parameter

Parameter	ParameterCommand Mode
IpmcQri	QRI Ranges 0-31744

Default

100

Command Mode

Configurate the command under VLAN configuration mode

Examplefor setting ORI

`Switch (config-if-vlan)# ip igmp snooping query-interval 110`

#### **4.7.13 ip igmp-snooping last-member-query-interval**

Command Description

- ✓ `ip igmp-snooping last-member-query-interval <IpmcLmqi : 0-31744>` For setting LLQI
- ✓ `no ip igmp-snooping last-member-query-interval`

For setting LLQI to default

Parameter

Parameter	ParameterCommand Mode
IpmcLmqi	LLQI ranges 0-31744

Default

10

Command Mode

Configurate the command under VLAN configuration mode

Examplefor setting LLOI

`Switch (config-if-vlan)# ip igmp snooping last-member-query-interval 20`

#### **4.7.14 ip igmp-snooping unsolicited-report-interval**

Command Description

- ✓ `ip igmp-snooping unsolicited-report-interval <IpmcUri : 0-31744>` For setting URI
- ✓ `no ip igmp-snooping unsolicited-report-interval`

For setting URI to default

Parameter

Parameter	ParameterCommand Mode
IpmcUri	URII ranges 0-31744

Default

10

### Command Mode

Configurate the command under VLAN configuration mode

Examplefor setting URI

```
Switch (config-if-vlan)# ip igmp snooping last-member-query-interval 200
```

### 4.7.15 show ip igmp snooping

Command Description

```
show ip igmp snooping [/detail/group-database/mrouter/vlan]
```

For checking IGMP configuration

Parameter

N/A

DefaultN/ACommand Mode

Configurate the command under Privilege mode

Examplefor checking IGMP configuration

```
Switch #show ip igmp snooping
```

## 4.8 MVR configuration

MVR configuration command :

- mvr
- mvr vlan
- mvr name
- mvr immediate-leave
- ipmc profile
- ipmc range
- show mvr
- show ipmc profile
- show ipmc range

### 4.8.1 Mvr

Command Description

Mvr, Enable global MVR mode

no mvr, Disable global MVR mode

Parameter N/A

Default

Disable

Command ModeGlobal Configuration Mode

Example

Switch(config)# mvr

Switch(config)# no mvr

#### 4.8.2 Mvr vlan

Command Description mvr vlan, Setting

MVR vlan port no mvr vlan, Delete mvr vlan

port settings Parameter

```
mvr vlan <v_vlan_list> [ name <mvr_name> ]      mvr vlan <v_vlan_list> channel <profile_name>
mvr vlan <v_vlan_list> frame priority <cos_priority>    mvr vlan <v_vlan_list> frame tagged
mvr vlan <v_vlan_list> igmp-address <v_ipv4_ucast>    mvr vlan <v_vlan_list> last-member-query-
interval <ipmc_lmqi>        mvr vlan <v_vlan_list> mode { dynamic | compatible }
```

Default

N/A

Command ModeGlobal Configuration Mode

Example

Switch(config)# mvr vlan 2 name test

Switch(config)# mvr vlan 2 mode compatible

#### 4.8.3 Mvr name

Command Description mvr

name, Setting MVR name no mvr

name, Delete MVR name

Parameter

```
mvr name <mvr_name> channel <profile_name>      mvr name <mvr_name> frame priority
<cos_priority>      mvr name <mvr_name> frame tagged      mvr name <mvr_name> igmp-address
<v_ipv4_ucast>      mvr name <mvr_name> last-member-query-interval <ipmc_lmqi>      mvr name
<mvr_name> mode { dynamic | compatible } DefaultN/A
```

Command ModeGlobal Configuration Mode

Example

Switch(config)# mvr name test igmp-address 222.0.0.1

Switch(config)# no mvr name test igmp-address 222.0.0.1

#### 4.8.7 show mvr

Command Description

Show mvr, For checking MVR configuration

Parameter

N/A

Default

N/A

Command Mode

Privilege Mode

Example

[Switch # Show mvr](#)

#### **4.8.8 show ipmc profile**

Command Description

Show ipmc profile, For checking ipmc profile configuration

Parameter

N/A

Default

N/A

Command Mode

Privilege Mode

Example

[Switch # Show ipmc profile](#)

### **4.9 Router Configuration**

Router Configuration Command :

- ip routing
- interface vlan
- ip address ip route
- show ip interfacebrief
- show ip route

#### **4.9.1 ip routing**

Command Description

- ✓ ip routing , Enable the function

- ✓ no ip routing, Disable the function

Parameter

N/A

Default

Host-only mode

Command Mode

Configurate the command under Global Configuration Mode

Example for enable ip routing

`Switch (config)#ip routing`

#### **4.9.2 interface vlan**

Command Description

`interface vlan<vlan_id>`

Parameter

Parameter	Parameter Command Mode
<code>vlan_id</code>	Vlan port ID ranges : vlan1-vlan4094.

Default

N/A

Command Mode

Under Global Configuration Mode, use command mode and this command, could be access to VLAN Port Configuration Mode

Example

Below command to VLAN1 Port Configuration Mode:

`switch(config)# interface vlan1`

`switch(config-if-vlan)# ip address 192.168.1.1 255.255.255.0`

#### **4.9.3 ip address**

Command Description

`<address><netmask>` For adding IP

of port no ip address

For deleting IP of port

Parameter

Parameter	ParameterCommand Mode
Address	Vlan IP addrees
Netmask	subnet mask

Default

VLAN 1

Command Mode

Configurate the command under VLAN Port Configuration Mode

Examplefor setting IP of VLAN 2

```
switch(config)# interface vlan 2
```

```
switch(config-if-vlan)# ip address 192.168.1.1 255.255.255.0
```

#### 4.9.4 ip route

Command Description

ip route <v\_ipv4\_addr><v\_ipv4\_netmask><v\_ipv4\_gw><v\_nhop\_vlanid> For adding a static route no ip route

Delete a static route

Parameter

Parameter	ParameterCommand Mode
v_ipv4_addr	IP
v_ipv4_netmask	Subnet mask
v_ipv4_gw	Gateway
v_nhop_vlanid	next VLAN

Default

N/A

Command Mode

Configurate the command under Global Configuration Mode Examplefor setting a static route

```
switch(config)# ip route 192.168.3.0 255.255.255.0 192.168.100.100 2
```

#### 4.9.5 show ip interface brief

Command Description

show ip interface brief

For checking IP of port

Parameter

N/A

Default

N/A

Command Mode

Configurate the command under Privilege mode

Examplefor checking IP of port

[Switch#show ip interface brief](#)

#### **4.9.6 show ip route**

Command Description

show ip route

For checking static route

Parameter

N/A

Default

N/A

Command Mode

Configurate the command under Privilege mode

Examplefor checking static route

[Switch#show ip route](#)

### **Chapter 5Network Security Command**

#### **5.1 MAC address table**

MAC address table configuration command : mac address-

table static mac address-table aging-time

show mac address-table

##### **5.1.1 mac address-table static**

Command Description

mac address-table static mac-addr vlan vlan-id interface interface-id For adding a static MAC address  
no mac address-table static mac-addr vlan vlan-id interface interface-id For deleting a static MAC address  
Parameter

Parameter	ParameterCommand Mode
mac-addr	MAC address
vlan-id	VLAN ID ranges for the MAC : 1—4094.
interface-id	All ports ID for the MAC

Default

N/A

Command Mode

Configurate the command under Global Configuration Mode

Examplefor setting MAC< 00-00-00-00-00-01> bond to Port 10 under VLAN2

`Switch(config)# mac address-table static 00-00-00-00-00-01 vlan 2 interface 1/10`

### **5.1.2 mac address-table aging-time**

Command Description

mac address-table aging-time For setting the aging time of the MAC address

no mac address-table aging time

For setting the MAC address aging time to default

Noted: If the value is 0, it indicates disable the automatic aging function

Parameter

Parameter	ParameterCommand Mode
Time	Aging time ranges : <0,10-1000000>

Default

N/A

Command Mode

Configurate the command under Global Configuration Mode

Examplefor setting the MAC address table aging time at 200s

`Switch(config)# mac address-table aging-time 200`

### **5.1.3 show mac address-table**

Command Description

show mac address-table {address | aging-time | conf | count | learning [[interface interface-id | vlan vlan-id] | static]}

For showing the MAC address table content of switch

Parameter

Parameter	ParameterCommand Mode
Address	Mac address checking
aging-time	Mac address table aging time.
Conf	For added static MAC address by user
Count	Total numbers of MAC address
Learning	Mac learning status
interface-id	Port name
vlan-id	VLAN ID valid ranges : 1—4094.
Static	Static MAC address table

DefaultN/A

Command Mode

Using the command to show MAC address table under Privilege Mode

Example for showing all MAC address tables

[Switch# show mac address-table](#)

## 5.2 Storm Broadcast control

Command Description

qos storm broadcast /unicast /unknown      Enable the function

no qos storm broadcast /unicast /unknown      Disable the function

Parameter

Parameter	ParameterCommand Mode
Broadcast	Broadcast data
Unicast	Single broadcast data
Unknown	Undefined Single broadcast data

Default

Disable

Command Mode

Configurate the command under Port Configuration Mode

Examplefor enable Storm Broadcast control at Port 10

**Switch(config)# interface GigabitEthernet 1/10**

**Switch (config-if)# qos storm broadcast**

### **5.3 IP VerifySource IP Verify Source**

Command Description

ip verify source ip verify

source translate ip verify

source limit

ip source binding interface

**Switch # show ip verify source**

#### **5.3.1 ip verify source**

Command Description

ip verify source Enable IP verify source

no ip verify source Disable IP verify source

Parameter

N/A

Default

Disable

Command Mode

Configurate the command under Global Configuration Mode

Examplefor enable IP verify source

**Switch (config)# ip verify source**

#### **5.3.2 ip verify source translate**

Command Description

ip verify source translate

For translating dynamic entry to static entry no ip

verify source translate

For cancel the translations

Parameter

N/A

Default

Disable

Command Mode

Configurate the command under Global Configuration Mode

Example

```
Switch (config)# ip verify source translate
```

### **5.3.3 ip verify source limit**

Command Description

ip verify source limit <0-2>

For limit the numbers of the dynamic client

no ip verify source limit For setting the limit to default

Parameter

Parameter	ParameterCommand Mode
<0-2>	Number ranges of dynamic client<0-2>

Default

Unlimited

Command Mode

Configurate the command under Port Configuration Mode

Example

```
Switch (config)# interface GigabitEthernet 1/1
```

```
Switch (config-if)# ip verify source limit 2
```

### **5.3.4 ip source binding interface**

Command Description ip source binding interface

<port\_type><in\_port\_type\_id><vlan\_var>  
<ipv4\_var><mask\_var>

For adding numbers of the static entry no ip source binding

interface<port\_type><in\_port\_type\_id><vlan\_var>

<ipv4\_var><mask\_var>

For deleting numbers of the static entry

Parameter

Parameter	ParameterCommand Mode
port_type	Port type
in_port_type_id	Port ID
vlan_var	vlan ID
ipv4_var	ip address
mask_var	Subnet mask

Default

N/A

Command Mode

Configurate the command under Global Mode

Examplefor adding a static item, whose Port ID is 1, Vlan ID is 1, IP address is 192.168.2.66, and the subnet mask is 255.255.255.0

`Switch(config)#ip source binding interface GigabitEthernet 1/1 1 192.168.2.66 255.255.255.0`

### 5.3.5 show ip verify source

Command Description show ip  
verify source

For checking IP verify source configuration status

Parameter

N/A

Default

Disable

Command Mode

Configurate the command under Privilege mode

Examplefor checking enable IP verify source configuration status

`Switch# show ip verify source`

## 5.4 ARP Inspection Configuration

ARP Testing Configuration Command :

ip arp inspection ip arp inspection trust ip arp inspection checking-vlan ip arp inspection logging ip arp inspection entry interface ip arp inspection translate ip arp inspection vlan show ip arp inspection

#### **5.4.1 ip arp inspection**

Command Description

- ✓ ip arp inspection Enable the IP ARP inspection
- ✓ no ip arp inspection Disable IP ARP inspection

Parameter

N/A

Default

Disable

Command Mode

Configurate the command under Global Configuration Mode

Example for enable ARP inspection

[Switch\(config\)# ip arp inspection](#)

#### **5.4.2 ip arp inspection trust**

Command Description

- ✓ ip arp inspection trust Disable ARP inspection for port
- ✓ no ip arp inspection trust Enable the ARP inspection for port

Parameter

N/A

Default

Disable the function

Command Mode

Configurate the command under Port Configuration Mode

Example for enable IP ARP inspection of port 10

[Switch \(config-if\)# no ip arp inspection trust](#)

#### **5.4.3 ip arp inspection checking-vlan**

Command Description

- ✓ ip arp inspection checking-vlan Enable ARP inspection checking-VLAN
- ✓ no ip arp inspection checking-vlan Disable ARP inspection checking-VLAN

Parameter

N/A

Default

Disable

Command Mode

Configurate the command under Port Configuration Mode

Examplefor enable ARP inspection checking-VLAN of port 10

**Switch (config-if)# ip arp inspection checking-vlan**

#### **5.4.4 ip arp inspection logging**

Command Description

- ✓ ip arp inspection logging all/deny/permit For setting Port logging type
- ✓ no ip arp inspection logging For setting port logging type to default

Parameter

Parameter	ParameterCommand Mode
All	All
Deny	Deny
Permit	Permit

Default

N/A

Command Mode

Configurate the command under Port Configuration Mode

Examplesetting logging type to “ Permit” of port 10

**Switch (config-if)# ip arp inspection logging permit**

#### **5.4.5 ip arp inspection entry interface**

Command Description

ip arp inspection entry interface <port\_type><in\_port\_type\_id><vlan\_var>  
<mac\_var><ipv4\_var>

For adding static entry no ip arp inspection entry interface

<port\_type><in\_port\_type\_id><vlan\_var>  
<mac\_var><ipv4\_var>

For deleting static entry

Parameter

Parameter	ParameterCommand Mode
port_type	Port type
port_type_id	Port ID
vlan_var	VLAN ID
mac_var	MAC
ipv4_var	IP address

Default

N/A

Command Mode

Configurate the command under Global Configuration Mode

Examplefor adding a static entry

```
Switch(config)# ip arp inspection entry interface GigabitEthernet 1/1 1 00:00:00:00:00:08 192.168.2.3
```

#### 5.4.6 ip arp inspection translate

Command Description

```
ip arp inspection translate [ interface <port_type><in_port_type_id>
<vlan_var><mac_var><ipv4_var> ]
```

For translating dynamic entry to static entry.

```
no ip arp inspection translate [ interface <port_type><in_port_type_id>
<vlan_var><mac_var><ipv4_var> ]
```

For cancel translated entry

Parameter

Parameter	ParameterCommand Mode
port_type	Port type
port_type_id	Port ID
vlan_var	VLAN ID
mac_var	MAC Address
ipv4_var	IP Address

Default

N/A

Command Mode

Configurate the command under Global Configuration Mode

Examplefor translating all dynamic entry to static entry

`Switch (config)# ip arp inspection translate`

#### **5.4.7 ip arp inspection vlan**

Command Description

`ip arp inspection vlan <in_vlan_list> logging { deny | permit | all }` For  
setting VLAN logging type no ip arp inspection vlan <in\_vlan\_list>  
`logging { deny | permit | all }`

For setting VLAN logging type to default

Parameter

Parameter	ParameterCommand Mode
All	all
Deny	deny
Permit	permit

Default

N/A

Command Mode

Configurate the command under Global Configuration Mode

Examplefor setting vlan 1 logging type at deny

`Switch (config)# ip arp inspection vlan 1 logging deny`

#### **5.4.8 show ip arp inspection**

Command Description

`show ip arp inspection entry/interface/vlan`

For checking ARP inspection related information configuration

Parameter

N/A

Default

N/A

Command Mode

Configurate the command under Privilege mod

Examplefor checking ARP inspection configuration

Switch # show ip arp inspection

## 5.5 ACL Configuration

ACL configuration command :

- access-list ace
- show access-list

### 5.5.1 access-list ace

Command Description

access-list ace , configuration for acl ace entry no

access-list ace, Deleteacl ace entry

Parameter

Ace id        ace entry id, ranges 1-512      action        permit/deny      dmac-type  
frame-type        ingress interface logging        logging frame information next  
Add a new ACE entry at current ACE entry        policy        Policy  
configurationselection rate-limiter        rate limit, this will occupy the rate limiter in  
bandwidth policy redirect        Port redirection configuration selection shutdown

Shut down port configuration selection

tag-priority    vlanTag priority level configuration selection vid

VID filter domainconfiguration selection

Default

Shutdown

Command Mode

Global Configuration Mode

Example

```
Switch(config)# access-list ace 1 ingress interface GigabitEthernet 1/1 frame-type ipv4 action deny rate-limiter 1 redirect interface GigabitEthernet 1/2 logging
```

```
Switch(config)# no access-list ace 1
```

### 5.5.2 Show access-list

### Command Description

Show access-list , For checking ace configuration information Parameter

```
show access-list [ interface [ ( <port_type> [ <v_port_type_list> ] ) ] ]
```

```
[ rate-limiter [ <rate_limiter_list> ] ] [ ace statistics [ <ace_list> ] ] show access-list ace-status  
[ static ] [ link-oam ] [ loop-protect ] [ dhcp ] [ ptp ] [ upnp ] [ arp-inspection ] [ evc ] [ mep ] [ ipmc ] [ ip-source-guard ] [ ip-mgmt ] [ conflicts ]
```

```
[ switch <switch_list> ]
```

Default

Shutdown

Command Mode

Privilege Configuration Mode

Example

```
Switch# show access-list ace statistics
```

```
Switch# show access-list ace
```

## 5.6 STP Configuration

STP Configuration Command :

```
spanning-tree spanning-tree mode spanning-tree aggregation spanning-tree auto-edge spanning-tree  
bpdu-guard spanning-tree edge spanning-tree link-type spanning-tree mst spanning-tree restricted-role  
spanning-tree restricted-tcn
```

### 5.6.1 spanning-tree

Command Description

spanning-tree Enable

STP no spanning-tree

Disable STP

Parameter

N/A

Default

Enable

Command Mode

Configurate the command under Port Configuration Mode or aggregate port configuration mode

Examplefor enable STP of port 10 and STP of aggregate port

```
Switch (config-if) #spanning-tree
```

Switch (config-stp-aggr)# spanning-tree

### 5.6.2 spanning-tree mode

Command Description

- ✓ spanning-tree mode stp/mstp/rstp For setting STP version
- ✓ no spanning-tree mode For setting STP version to default

Parameter

N/A Default

mstp

Command Mode

Configurate the command Global Configuration Mode

Examplefor modifying STP version to RSTP

Switch (config) #spanning-tree mode rstp

### 5.6.3 spanning-tree aggregation

Command Description

spanning-tree aggregation, For accessing to aggregate port STP configuration mode

Parameter

N/A

Default

N/A

Command Mode

Configurate the command under Global Configuration Mode

Examplefor accessing aggregate port STP configuration mode

Switch (config) #spanning-tree aggregation

### 5.6.4 spanning-tree auto-edge

Command Description

- ✓ spanning-tree auto-edge For enable auto-edge
- ✓ no spanning-tree auto-edge For disable auto-edge

Parameter

N/A

Default

Enable

Command Mode

Configurate the command under Port Configuration Mode or aggregate port configuration mode

Examplefor enable the auto-edge function of port 10 and aggregate port

`Switch (config-if) #spanning-tree auto-edge`

`Switch (config-stp-aggr)# spanning-tree auto-edge`

### **5.6.5 spanning-tree bpdu-guard**

Command Description

- ✓ `spanning-tree bpdu-guard` Enable BPDU Guard
- ✓ `no spanning-tree bpdu-guard` Disable BPDU Guard

Parameter

N/A

Default

Disable

Command Mode

Configurate the command under Port Configuration Mode or Aggregate Port Configuration mode

Examplefor enable BPDU Guard of port 10 and aggregate port

`Switch (config-if) #spanning-tree bpdu-guard`

`Switch (config-stp-aggr)# spanning-tree bpdu-guard`

### **5.6.6 spanning-tree edge**

- ✓ Command Description `spanning-tree edge` Enable management of edge function
- ✓ `no spanning-tree edge` Disable management of edge function

Parameter

N/A

Default

Non-Edge

Command Mode

Configurate the command under Port Configuration Mode or Aggregate Port configuration Mode

Examplefor enable management of edge function of port 10 and aggregate port

`Switch (config-if) #spanning-tree edge`

Switch (config-stp-aggr)# spanning-tree edge

### 5.6.7 spanning-tree link-type

Command Description

- ✓ spanning-tree link-type auto/ point-to-point/ shared For configurating point-to-point type
- ✓ no spanning-tree link-type For configurating point-to point type to default

Parameter

Parameter	ParameterCommand Mode
Auto	auto for corresponding web interface
point-to-point	forced true for corresponding webinterface
shared	forced false for corresponding web interface

Default auto

Command Mode

Configurate the command under Port Configuration Mode or Aggregate port configuration mode

Examplefor configurating point-to-point type to forced true of port 10 and aggregate port

Switch (config-if)# spanning-tree link-type point-to-point

Switch (config-stp-aggr)# spanning-tree link-type point-to-point

### 5.6.8 spanning-tree mst

Command Description

spanning-tree mst <instance> cost { <cost> | auto } For setting path cost no spanning-tree mst <instance> cost { <cost> | auto } For setting path cost to default spanning-tree mst <instance> port-priority <prio> For setting port priority no spanning-tree mst <instance> port-priority <prio>

For setting port priority back to default

Parameter

Parameter	ParameterCommand Mode
instance	Ranges 0-7
Cost	Integer of the ranges 1200000000

Prio	Ranges 0-240
------	--------------

Default

N/A

Command Mode

Configurate the command under Port Configuration Mode or aggregate port configuration configuration mode

Examplefor setting path cost of port 10 and aggregate port

`Switch (config-if) # spanning-tree mst 1 cost 144`

`Switch (config-stp-aggr)# spanning-tree mst 1 cost 144`

### **5.6.9 spanning-tree restricted-role**

Command Description

- ✓ `spanning-tree restricted-role` Enable restricted role
- ✓ `no spanning-tree restricted-role` Disable restricted role

ParameterN/A

Default

Disable

Command Mode

Configurate the command under Port Configuration Mode or aggregate port configuration mode

Example for enable restricted role of port 10 and aggregate port

`Switch (config-if) # spanning-tree restricted-role`

`Switch (config-stp-aggr)# spanning-tree restricted-role`

### **5.6.10 spanning-tree restricted-tcn**

Command Description

`spanning-tree restricted- tcn`

Enable restricted tcn no spanning-  
tree restricted- tcn

Disable restricted tcn

Parameter

N/A

Default

Disable

## Command Mode

Configurate the command under Port Configuration Mode or Aggregate port configuration mode

Example for enable restricted tcn of port 10 and aggregate port

**Switch (config-if) # spanning-tree restricted- tcn**

**Switch (config-stp-aggr)# spanning-tree restricted- tcn**

### **5.6.11 show spanning-tree**

#### Command Description

show spanning-tree /active/ detailed/ interface / mst / summary

For checking STP related configuration

#### Parameter

N/A

#### Default

N/A

#### Command Mode

Configurate the command under Privilege Configuration Mode

Examplefor checking STP configuration status

**Switch # show spanning-tree**

## **5.7 Loop-protect configuration**

### Loop-protect configuration command

**loop-protect loop-protect tx-mode**

### **5.7.1 loop-protect**

#### Command Description

- ✓ **loop-protect** Enable loop-protect
- ✓ **no loop-protect** Disable loop-protect

#### Parameter

N/A

#### Default

Disable

#### Command Mode

Configurate the command under Global Configuration Mode

Example for enable loop-protect

Switch (config) # loop-protect

### 5.7.2 loop-protect tx-mode

Command Description

- ✓ loop-protect tx-mode Enable loop-protect tx-mode
- ✓ no loop-protect tx-mode Disable loop-protect tx-mode

Parameter

N/A

Default

Disable

Command Mode

Configurate the command under Port Configuration Mode

Example for enable loop-protect tx-mode

Switch (config-if) #loop-protect tx-mode

## 5.8 ERPS configuration

ERPS configuration command :

- ✓ Mep
- ✓ Erps

Noted: command for erps is complicated, suggest to configurated by web. More easier to do. 5.8.1

mep

Command Description

Reference to

Example

Parameter Reference to

Example

Default Reference to

Example

Command Mode

Global Mode

Example

//Configurtate Port 1, 2 into ERPS group 1, protocol vlan3001, the major port without configurating

Switch(config)# mep 1 down domain port flow 1 level 0 interface GigabitEthernet 1/1

```
Switch(cinfig)# mep 1 vid 3001
Switch(cinfig)# mep 1 aps 0 raps
Switch(cinfig)# mep 2 down domain port flow 2 level 0 interface GigabitEthernet 1/2
Switch(cinfig)# mep 2 vid 3001
Switch(cinfig)# mep 2 aps 0 raps
Switch(cinfig)# erps 1 major port0 interface GigabitEthernet 1/1 port1 interface GigabitEthernet 1/2
Switch(cinfig)# erps 1 mep port0 sf 1 aps 1 port1 sf 2 aps 2
Switch(cinfig)# erps 1 vlan 1
```

### **5.8.2 erps**

Command Description

Reference to

Example

Parameter

Reference to Example

DefaultReference to Example Command

ModeGlobal Mode

Example// Configurate port 51, 52 into ERPS group 2, protocol vlan3002, Major port- port 0

```
Switch(cinfig)# mep 51 down domain port flow 51 level 0 interface XGigabitEthernet 1/3
```

```
Switch(cinfig)# mep 51 vid 3002
```

```
Switch(cinfig)# mep 51 aps 0 raps
```

```
Switch(cinfig)# mep 52 down domain port flow 52 level 0 interface XGigabitEthernet 1/4
```

```
Switch(cinfig)# mep 52 vid 3002
```

```
Switch(cinfig)# mep 52 aps 0 raps
```

```
Switch(cinfig)# erps 2 major port0 interface XGigabitEthernet 1/3 port1 interface XGigabitEthernet 1/4
```

```
Switch(cinfig)# erps 2 mep port0 sf 51 aps 51 port1 sf 52 aps 52
```

```
Switch(cinfig)# erps 2 rpl owner port0
```

```
Switch(cinfig)# erps 2 vlan 1
```

## Chapter 6 Network Management Command

### 6.1 SSH Configuration

SSH Configuration Command :

ip ssh no

ip ssh

#### 6.1.1 ip ssh

Command Description

ip ssh

For enable SSH no

ip ssh

For disable SSH, under this situation, cannot manage switch via SSH

Parameter

N/A

Default

N/A

Command Mode

Configurate the command under Global Configuration Mode

Example for enable SSH

Switch(config)# ip ssh

### 6.2 HTTP Configuration

Configuration Command :

- ip http secure-server
- ip http-serve- redirect

#### 6.2.1 ip http-server-server

Command Description

✓ ip http secure-server Enable the HTTP service

✓ no ip http secure-server Disable the HTTP service, at this situation, cannot manage switch via HTTPS

Parameter

N/A

Default

Disable

Command Mode

Configurate the command under Global Configuration Mode

Example for enable HTTPS service

`Switch(config)# ip http server-server`

### **6.2.2 ip http-server-redirect**

Command Description

ip http-server- redirect

For setting switch redirect to https service automatically

no ip http-server- redirect

For delete the settings, won't redirect to HTTPS to manage the switch. But could manage switch via HTTP

Parameter

N/A

Default

Disable

Command Mode

Configurate the command under Global Configuration Mode

Examplefor enable HTTPS-server redirect

`Switch(config)# ip http-server- redirect`

## **6.3 LLDP Configuration**

LLDP Configuration command :

- Lldp
- lldp holdtime
- lldp transmission-delay
- lldp timer
- lldp reinit
- show lldp neighbors

### **6.3.1 lldp**

Command Description

lldp receive , Setting port LLDP receive lldp transmit , Setting port LLDP receive

and transmit

No lldp receive|transmit, Shut down port LLDP receive/ transmit

Parameter

N/A

Default

Shut down

Command Mode

Port configuration mode

Example

```
Switch(config)# lldp receive
```

```
Switch(config)# lldp transmission-delay 1
```

```
Switch(config)# no lldp transmission-delay 1
```

### **6.3.2 lldp holdtime**

Command Description

lldp holdtime, Setting LLDP transmit time for holdtime nolldp

holdtime, Setting LLDP transmit time for holdtime to default

Parameter

<time>, Valid ranges 2-10, second

Default

4

Command Mode

Global Configuration Mode

Example

```
Switch(config)# lldp timer 5
```

```
Switch(config)# no lldp timer 5
```

```
Switch# show lldp neighbors
```

## **6.4 802.1X Configuration**

802.1x Configuration Command :

- dot1x system-auth-control
- dot1x port-control auto
- dot1x port-control mac-based
- dot1x port-control single
- dot1x port-control force-unauthorized
- dot1x re-authentication

- show dot1x statistics

Noted: It needs to shutdown STP of the port if needs enable 802.1x

#### **6.4.1 dot1x system-auth-control**

Command Description

- ✓ dot1x system-auth-control, This command could global enable 802.1x NAS
- ✓ no dot1x system-auth-control, This command could global disable 802.1x NAS

Parameter

N/A

Default

Shutdown

Command Mode

Global Configuration Mode

Example

```
Switch(config)# dot1x system-auth-control  
Switch(config)# no dot1x system-auth-control
```

#### **6.4.2 dot1x port-control auto**

Command Description

- ✓ dot1x port-control auto, For setting port identification to Port\_Based 802.1x
- ✓ no dot1x port-control, For setting port identification to default

Parameter

N/A

Default force-authorized

Command Mode

Port Configuration Mode

Example

```
Switch(config-if)# dot1x port-control auto
```

#### **6.4.3 dot1x port-control mac-based**

Command Description

dot1x port-control mac-based, For setting port identification to mac\_Based 802.1x

no dot1x port-control , For setting port identification to default

Parameter

N/A

Default force-authorized

Command ModePort Configuration Mode

Example

```
Switch(config-if)# dot1x port-control mac-based
```

#### **6.4.4 dot1x port-control single**

Command Description

- ✓ dot1x port-control single, For setting port identification to single 802.1x
- ✓ no dot1x port-control , For setting port identification to default

Parameter

N/A Default

force-authorized

Command Mode

Port Configuration Mode

Example

```
Switch(config-if)# dot1x port-control single
```

#### **6.4.5 dot1x port-control force-unauthorized**

Command Description

- ✓ dot1x port-control force-unauthorized, For setting port identification to force-unauthorized
- ✓ no dot1x port-control , For setting port identification to default

Parameter

N/A

Default

force-authorized

Command Mode

Port Configuration Mode

Example

```
Switch(config-if)# dot1x port-control force-unauthorized
```

#### **6.4.6 dot1x re-authentication**

Command Description

dot1x re-authentication , Global enable port re-authentication

no dot1x re-authentication, Global disable port re-authentication

Parameter

N/A

Default

Shutdown

Command ModeGlobal Configuration Mode

Example

Switch(config)# dot1x re-authentication

Switch(config)# no dot1x re-authentication

#### **6.4.7 dot1x authentication timer re-authenticate**

Command Description

- ✓ dot1x authentication timer re-authenticate <1-3600> , Global configurate port reauthentication time
- ✓ no dot1x authentication timer re-authenticate, configurate port re-authentication time to default

Parameter

<1-3600> 1-3600, second

Default

3600

Command Mode

Global Configuration Mode

Example

Switch(config)# dot1x authentication timer re-authenticate 1000

Switch(config)# no dot1x authentication timer re-authenticate

#### **6.4.8 show dot1x statistics**

Command Description

show dot1x statistics, For checking port identification statistics

Parameter

N/A

DefaultN/A

Command Mode

Privilege configuration Mode

Example

[Switch# show dot1x status](#)

## 6.5 SNMP Configuration

SNMP Configuration Command :

snmp snmp version

### 6.5.1 snmp

Command Description

- ✓ snmp , Enable SNMP
- ✓ no snmp , Disable SNMP

Parameter

N/A

Default

Enable

Command Mode

Configurate the command under Global Configuration Mode

Examplefor enable SNMP

[Switch\(config\)# snmp](#)

### 6.5.2 snmp version

Command Description

- ✓ snmp version,Enable setting SNMP Version
- ✓ no snmp version, Setting SNMP Version to default

Parameter

N/A Default

snmp v2c

Command Mode

Configurate the command under Global Configuration Mode

Example for configuring SNMP Version

```
Switch(config)# snmp version v2c
```

## Chapter 7 System Maintenance Command

### 7.1 Devise Reboot Command :

reload cold

#### 7.1.1 reload cold

Command Description reload cold , for rebooting device

Parameter

N/A

Default

N/A

Command Mode

Configure the command under Privilege Mode Example for rebooting device after save all configuration

```
switch# copy running-config startup-config
```

```
switch# reload cold
```

### 7.2 Restore to default

Restore to default command :

reload defaults

#### 7.2.1 reload defaults

Command Description

reload defaults, For restoring to default, after it, the device will back to default after rebooting Parameter  
N/A

Default

N/A

## Command Mode

Configurate the command Privilege Mode

Examplefor restoring to default

```
switch# reload defaults
```

### 7.3 ping testing

Ping testing command :

```
ping ip
```

#### 7.3.1 ping ip

Command Description

```
ping ip _addr
```

Parameter

Parameter	ParameterCommand Mode
Ip_addr	Ip address, valid ranges X.X.X.X.

Default

N/A

Command Mode

Configurate the command under Privilege Mode Examplefor testing connection

Between switch and mainframe

```
switch# ping ip 192.168.255.387
```

```
PING server 192.168.2.1, 56 bytes of data.  
64 bytes from 192.168.2.1: icmp_seq=0, time=0ms  
64 bytes from 192.168.2.1: icmp_seq=1, time=0ms  
64 bytes from 192.168.2.1: icmp_seq=2, time=0ms  
64 bytes from 192.168.2.1: icmp_seq=3, time=0ms  
64 bytes from 192.168.2.1: icmp_seq=4, time=0ms
```

# Configuragation User Manual

## Managed switches

شرکت سپیتم



[www.sepitam.com](http://www.sepitam.com)